



# Z-Zero-Setter



**HP-50A**



ORDER NO.	H	STYLE	WEIGHT(kg)	CODE NO.
HP-50A	50mm	STANDARD TYPE	1.1	3403-020
HP-50B		STANDARD TYPE	1.7	3403-021
HP-50AM	50mm	WITH MAGNETIC BASE	1.1	3403-022
HP-50BM		WITH MAGNETIC BASE	1.7	3403-023

1. Have the central measuring portion of the zero setter presetter against a plain surface and aligned if with the outer reference surface. Turn the dial gauge for zero setting.
2. Have the cutter touched against the z zero setter. Once the indicator position at zero the distance between the tool tip to workpiece is 50mm.



**HP-50B**